

# IMPORTANT

## PUSH AND HOLD THE GREEN BUTTON (A) AND TRIGGER (B) TO RUN

- 1) Flip power switch “ON”.
- 2) Push and hold the green button (A)
- 3) Get the scooter moving to 3MPH before you press the trigger (B). MOTOR WILL NOT START IF YOU JUST PRESS THE TRIGGER.
- 4) Once the scooter is moving at 3MPH press the trigger (B) to start the motor.
- 5) Green button (A) AND trigger (B) must BOTH be pressed and held to run scooter.
- 6) No pushing is required again unless scooter is moving slower than 3MPH and the trigger (B) has been released.



Rev.1.20.05 Razor USA LLC